


NICO & YEYE

MINIMO BOOK CASE



PRE-ASSEMBLY:

- Adult assembly required.
- Please review product assembly manual before using and or attempting to assemble furniture.
- Please review our Warnings and Warranty manual.
- Remove all parts and hardware from the box and lay out on a flat, carpeted, or scratch-free surface, this will avoid damaging any parts during assembly. Do not dispose of any contents until assembly is completed to avoid accidentally discarding.


CUSTOMER SERVICE

If you are missing parts or have any questions about this product, please contact us at customerservice@nicoandyeye.com or (866) NIC YEYE


ASSEMBLY INSTRUCTIONS

PARTS IDENTIFIER

NOTE: PARTS NOT SHOWN TO ACTUAL SIZE



PART	DESCRIPTION	QUANTITY
A	Top Book Case	1
B	Legs	4



Lay top book case (A) on level ground. Hand screw in legs (B) to top book case (A).