


# Tippy Toe Stool



## PRE-ASSEMBLY:


- Adult assembly required.
- Please review product assembly manual before using and or attempting to assemble furniture.
- Please review our Warnings and Warranty manual.
- Remove all parts and hardware from the box and lay out on a flat, carpeted, or scratch-free surface, this will avoid damaging any parts during assembly. Do not dispose of any contents until assembly is completed to avoid accidentally discarding.
- Do not fully tighten all bolts until all parts are in place. Failure to follow these instructions may cause the bolts to misalign during assembly.
- If using power tools to aid in assembly please use caution. Power tools can damage hardware or split wood.


#### **CUSTOMER SERVICE**

# **ASSEMBLY INSTRUCTIONS**


### PARTS IDENTIFIER

NOTE: PARTS NOT SHOWN TO ACTUAL SIZE







PART	DESCRIPTION	QUANTITY
Α	Seat Top	1
В	Stool Legs	4



Lay round seat top (A) on level ground color face down.



Screw in stool legs (B) to round seat top (A) as seen in image. Adjust until tight.



Enjoy!

3